

Huck® BOM® Tooling/Nose Assembly Selection

BOM®									
NOSE ASSEMBLY	FASTENER TYPE	FASTENER DIAMETER	FASTENER DIAMETER	LENGTH	RELEASE (JAWS)	COMMENTS	BATTERY TOOL	PNEUDRAULIC TOOL	HYDRAULIC TOOL
99-1314	BOM	-08	1/4"	LONG	NSR	-----	N/A	256	2581
99-1272*	BOM	-12	3/8"	STD	NSR	Low VOLUME	N/A	256*	2581*
99-5100	BOM	-16	1/2"	STD	SR	-----	N/A	N/A	2620
99-5101	BOM	-16	1/2"	STD	SR	Pass Thru	N/A	N/A	2620-PT
99-5102*	BOM	-20	5/8"	STD	SR	-----	N/A	N/A	3585*
99-5103*	BOM	-24	3/4"	STD	SR	-----	N/A	N/A	3585*
99-3119	BOM	-10	5/16"	STD	NSR	-----	N/A	N/A	2600B
99-3122	BOM	-12	3/8"	STD	NSR	-----	N/A	N/A	2600B
99-1053*	BOM	-06	3/16"	STD	NSR	-----	N/A	256*	2581*
99-994	BOM	-06	3/16"	STD	NSR	-----	BV4500-118K2	N/A	2480
H99-876	BOM	-12	3/8"	STD	SR	Pass Thru	N/A	N/A	2620-PT
99-876	BOM	-12	3/8"	STD	SR	-----	N/A	N/A	2620
99-830-1*	BOM	-08	1/4"	STD	NSR	-----	N/A	256*	2581*
99-769-2	BOM	-10	5/16"	XLONG	NSR	-----	N/A	256	2581
99-769*	BOM	-10	5/16"	STD	NSR	-----	N/A	256*	2581*
99-3124	BOM	-12	3/8"	STD	SR	-----	N/A	N/A	2600B
99-5106*	BOM	-16	1/2"	STD	SR	FLOATING EJECTOR, PASS THRU	N/A	N/A	2624PTD*
99-5107	BOM	-16	1/2"	STD	SR	-----	N/A	N/A	2624, 3585
99BOM-12-FRAH*	BOM	-12	3/8"	STD	NSR	FLOATING EJECTOR	N/A	N/A	2600B*

hfsindustrial.com
[YouTube.com/HFSIndustrial](https://www.youtube.com/HFSIndustrial)

The information contained in this publication is only for general guidance, and is not intended to create any warranty, express, implied, or statutory; all warranties are contained only in Howmet Fastening Systems' written quotations, acknowledgments, and/or purchase orders. It is recommended that the user secure specific, up-to-date data and information regarding each application and/or use of such products.

North America

Waco Operations
 PO Box 8117
 8001 Imperial Drive
 Waco, TX 76714-8117
 Tel: +1 800-388-4825
 Fax: +1 800-798-4825
sales.waco@howmet.com

Kingston Operations
 1 Corporate Drive
 Kingston, NY 12401
 Tel: +1 800-278-4825
 Fax: +1 845-334-7333
sales.kingston@howmet.com